



Enable Bi-Directional USB Serial Emulation Mode



Send Numbers as Keypad Data



All data is sent as if it has been entered on a keypad.





Enable Swiss Keyboard

Enable "D/E" Disable



The scanner will disable scanning after it receives after it receives and ASCII "D" from the host device. It will enable scanning when it receives an ASCII "E".

SECTION P

Enable



SECTION P

Enable Full Speed USB



Adds the ability to encode scanner serial number in NOVRAM.

Enable "F/L" Laser Command



The scanner will turn off the after it receives an ASCII "L" character.

BEEPER UPTIONS



3 Redundant Scans



Requires 4 consecutive decodes of the same bar code data for a "good scan".



