

PORS - OPOSTEST: Programming Barcodes for MP7000

Configuration name in Utility : PORS - OPOSTEST
Last Modified : 23-řij-20
Windows Filename : Config File_MP7000_PORS - OPOSTEST_2020.10.23.scncfg
Plug-in Name : MP7000-COMMON SR MODELS-024
Report Type : Only parameters changed from defaults shown



PORS - OPOSTEST: Programming Barcodes for MP7000

Configuration name in Utility : PORS - OPOSTEST
Last Modified : 23-řij-20
Windows Filename : Config File_MP7000_PORS - OPOSTEST_2020.10.23.scncfg
Plug-in Name : MP7000-COMMON SR MODELS-024
Report Type : Only parameters changed from defaults shown



Set Factory Defaults

Cable Connection Settings

IBM-RS485

PortAddress None

USB

USB Device Type IBM OPOS (IBMHH Full Scan Disable)

Symbology (bar code type) Settings

Code 128

Code 128 Enable

Code 39

Code 39 Enable

Interleaved 2 of 5

Interleaved 2 of 5 Enable

Interleaved 2 of 5 Length 1 0

General Parameter Settings

Beeper

Beeper Tone OFF

Configuration File PORS - OPOSTEST

PORS - OPOSTEST: Programming Barcodes for MP7000

Configuration name in Utility : PORS - OPOSTEST
Last Modified : 23-řij-20
Windows Filename : Config File_MP7000_PORS - OPOSTEST_2020.10.23.scncfg
Plug-in Name : MP7000-COMMON SR MODELS-024
Report Type : Only parameters changed from defaults shown



Firmware:


CAADGS00-002-R08

Supported Scanner Models for Plug-in :

MP7000-LHS0M00WW
MP7000-LND0M00WW
MP7000-LNS0C00WW
MP7000-LNS0M00IN
MP7000-LNS0M00WW
MP7000-LNS0P00WW
MP7000-MHS0M00WW
MP7000-MHSLM00WW
MP7000-MND0M00WW
MP7000-MNDDC00WW
MP7000-MNDDM00WW
MP7000-MNDDP00WW
MP7000-MNDLM00WW
MP7000-MNS0C00WW
MP7000-MNS0M00WW
MP7000-MNS0P00WW
MP7000-MNSDC00WW
MP7000-MNSDM00WW
MP7000-MNSDP00WW

PORS - OPOSTEST: Programming Barcodes for MP7000

Configuration name in Utility : PORS - OPOSTEST
Last Modified : 23-řij-20
Windows Filename : Config File_MP7000_PORS - OPOSTEST_2020.10.23.scncfg
Plug-in Name : MP7000-COMMON SR MODELS-024
Report Type : Only parameters changed from defaults shown



MP7000-MNSLC00WW
MP7000-MNSLM00WW
MP7000-MNSLP00WW
MP7000-SHS0M00WW
MP7000-SND0M00WW
MP7000-SNS0C00WW
MP7000-SNS0M00IN
MP7000-SNS0M00WW
MP7000-SNS0P00WW
MP7000-SVS0M00WW
MP7010-LNS0M00WW
MP7010-MNS0M00WW
MP7010-MNSLM00WW
MP7010-SNS0M00WW
MP7010-SPS0M00WW
MP7000-LHS0P18WW