


Blue tooth printer paring with windows device


1. Checking BT name and password from self test, pressing “FEED” and power on, release your hand from “FEED” once printer beeping, you will get a self test as below pic:




2. Entering into “printers and Faxes” as below pic:




3. Click “add a device, next, as below pic:




4. Selecting a device to add this computer, next, as below pic:



5. Selecting a pairing option, next, as below:




6. Input the password, next, as below pic:




7. Connected.

8. Checking the right port from printers and faxes, as below pic:



9. Printer pairing success, then open “pos-test” to test printer, as below pic:



①② Choosing the right port from printers and faxes

③ Print

Blue tooth printer connected success if printer print with receipt.