Bluetooth printer paring with android device

1. Checking BT name and password from self test, method:pressing "FEED" and power on, release your hand from "FEED" once printer beeping, you will get a self test as below pic:

2.Setting bluetooth from user setting,as below pic:

3. Searching blue tooth device automatically, as below pic:

4.Finding the printer name and inputting pass word,as below

pic:

5.Connected!